



BlitzBuds™

Wireless headphones

User manual

EN

1. Product Presentation:

The wireless TWS headphones are designed for wireless audio playback and for making phone calls using Bluetooth technology in connection with compatible devices. This product is intended for consumer use only. It is not a personal protective equipment and does not provide hearing protection. The product must be used according to the instructions provided in this manual.

2. Package Contents:

- 3mk BlitzBuds wireless headphones,
- charging case,
- user manual,
- interchangeable ear tips,
- USB-C charging cable.

3. Technical Specification:

- Name: 3mk BlitzBuds
- Model: TWS-BLITZ-01W
- Bluetooth Version: 6.0
- Audio Codecs: AAC, SBC
- Radio Frequency Band: 2402 MHz-2480 MHz
- Speaker Size: 10 mm
- Impedance: 32 Ω
- Charging Port: USB-C

- Frequency Range: 20-20000 Hz
- Headphones Charging Time: 1 h
- Charging Case Charging Time: 2 h
- Playback Time: 6h (26h with charging case)
- Standby Time: up to 120 h
- Headphone Battery Capacity: 40 mAh
- Charging Case Battery Capacity: 500 mAh
- Bluetooth Signal Range: up to 10 m
- Headphone Charging Current: 75 mA
- Charging Case Charging Current: 350 mA
- Maximum Transmit Power: ≤8 dBm
- Nominal Battery Voltage: 3.7 V
- Sound Pressure Level (SPL): 106.5 dB ± 3 @ 1 KHz
- Bluetooth Profiles: HSP, HFP, A2DP, AVRCP
- Battery Type: lithium-polymer battery
- Nominal Input Voltage and Current: 5 V / 350 mA

4. User Instructions:

Unless the user manual of the devices you wish to charge states otherwise, please follow these steps:

- It is recommended to use the original charging cable included in the package for charging.
- Do not use chargers or fast charging technologies unless specified otherwise in the product specifications.
- Before first use, charge the charging case.
- The indicator lights on the charging case will blink red while charging with the USB-C cable. Once fully charged,

the lights stop blinking and show a steady red light.

Charging Headphones:

- Place the headphones in the charging case to charge them when they signal a low battery level.

Left Headphone Functions:

- Play music: tap twice

- Pause music: tap twice

- Previous track: tap three times

- Decrease volume: tap once

- Player mode ON/OFF: tap four times

Right Headphone Functions:

- Play music: tap twice

- Pause music: tap twice

- Next track: tap three times

- Increase volume: tap once

- Voice assistant: press and hold for 2 seconds

Calling Functions:

- Answer a call: tap twice (left or right headphone)

- End a call: tap twice (left or right headphone)

- Reject a call: press and hold for 2 seconds

Turning On Headphones:

1. Open the charging case lid, the headphones will automatically turn on.

Turning Off Headphones:

1. Place the headphones in the case and then close it – the headphones will turn off.

Bluetooth Pairing:

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss:

- Listening to sound at high volume can permanently damage hearing.
 - When using headphones for listening to music or making calls, it is recommended to use the minimum volume required for music or calls to avoid hearing damage.
 - Prolonged exposure to loud sounds may lead to irreversible hearing damage.
 - Exposure to loud sounds while driving can distract attention and lead to accidents.
- Operating Environment:**
- Do not use the device in dusty, heavily soiled, or small spaces or near magnetic fields to avoid internal circuit failure.
 - Avoid strong magnetic fields or electrical devices that generate such fields while using the device.
 - Do not use the device during a storm. Lightning storms can cause equipment failure or electric shock hazards.
 - The device should be used in temperature ranges of – 0°C to 40°C, and the device and its accessories should be stored in temperature ranges of -10°C to 45°C. Too high or too low ambient temperature may cause device failure. At temperatures below -10°C, battery performance is limited.
 - Do not place the device in direct sunlight, such as on a car dashboard.
 - Do not place the device near heat sources or open flames, such as electric heaters, ovens, water heaters,

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss:

- Listening to sound at high volume can permanently damage hearing.
 - When using headphones for listening to music or making calls, it is recommended to use the minimum volume required for music or calls to avoid hearing damage.
 - Prolonged exposure to loud sounds may lead to irreversible hearing damage.
 - Exposure to loud sounds while driving can distract attention and lead to accidents.
- Operating Environment:**
- Do not use the device in dusty, heavily soiled, or small spaces or near magnetic fields to avoid internal circuit failure.
 - Avoid strong magnetic fields or electrical devices that generate such fields while using the device.
 - Do not use the device during a storm. Lightning storms can cause equipment failure or electric shock hazards.
 - The device should be used in temperature ranges of – 0°C to 40°C, and the device and its accessories should be stored in temperature ranges of -10°C to 45°C. Too high or too low ambient temperature may cause device failure. At temperatures below -10°C, battery performance is limited.
 - Do not place the device in direct sunlight, such as on a car dashboard.
 - Do not place the device near heat sources or open flames, such as electric heaters, ovens, water heaters,

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss:

- Listening to sound at high volume can permanently damage hearing.
 - When using headphones for listening to music or making calls, it is recommended to use the minimum volume required for music or calls to avoid hearing damage.
 - Prolonged exposure to loud sounds may lead to irreversible hearing damage.
 - Exposure to loud sounds while driving can distract attention and lead to accidents.
- Operating Environment:**
- Do not use the device in dusty, heavily soiled, or small spaces or near magnetic fields to avoid internal circuit failure.
 - Avoid strong magnetic fields or electrical devices that generate such fields while using the device.
 - Do not use the device during a storm. Lightning storms can cause equipment failure or electric shock hazards.
 - The device should be used in temperature ranges of – 0°C to 40°C, and the device and its accessories should be stored in temperature ranges of -10°C to 45°C. Too high or too low ambient temperature may cause device failure. At temperatures below -10°C, battery performance is limited.
 - Do not place the device in direct sunlight, such as on a car dashboard.
 - Do not place the device near heat sources or open flames, such as electric heaters, ovens, water heaters,

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss:

- Listening to sound at high volume can permanently damage hearing.
 - When using headphones for listening to music or making calls, it is recommended to use the minimum volume required for music or calls to avoid hearing damage.
 - Prolonged exposure to loud sounds may lead to irreversible hearing damage.
 - Exposure to loud sounds while driving can distract attention and lead to accidents.
- Operating Environment:**
- Do not use the device in dusty, heavily soiled, or small spaces or near magnetic fields to avoid internal circuit failure.
 - Avoid strong magnetic fields or electrical devices that generate such fields while using the device.
 - Do not use the device during a storm. Lightning storms can cause equipment failure or electric shock hazards.
 - The device should be used in temperature ranges of – 0°C to 40°C, and the device and its accessories should be stored in temperature ranges of -10°C to 45°C. Too high or too low ambient temperature may cause device failure. At temperatures below -10°C, battery performance is limited.
 - Do not place the device in direct sunlight, such as on a car dashboard.
 - Do not place the device near heat sources or open flames, such as electric heaters, ovens, water heaters,

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss:

- Listening to sound at high volume can permanently damage hearing.
 - When using headphones for listening to music or making calls, it is recommended to use the minimum volume required for music or calls to avoid hearing damage.
 - Prolonged exposure to loud sounds may lead to irreversible hearing damage.
 - Exposure to loud sounds while driving can distract attention and lead to accidents.
- Operating Environment:**
- Do not use the device in dusty, heavily soiled, or small spaces or near magnetic fields to avoid internal circuit failure.
 - Avoid strong magnetic fields or electrical devices that generate such fields while using the device.
 - Do not use the device during a storm. Lightning storms can cause equipment failure or electric shock hazards.
 - The device should be used in temperature ranges of – 0°C to 40°C, and the device and its accessories should be stored in temperature ranges of -10°C to 45°C. Too high or too low ambient temperature may cause device failure. At temperatures below -10°C, battery performance is limited.
 - Do not place the device in direct sunlight, such as on a car dashboard.
 - Do not place the device near heat sources or open flames, such as electric heaters, ovens, water heaters,

- When removing the headphones from the case, they will automatically turn on and the indicator will start to blink; then select the Bluetooth name "3mk BlitzBuds" on your device to connect.

Pairing Bluetooth with another device:

1. If a previously paired device is nearby, go to Bluetooth settings and disconnect the current connection with the headphones, then they will switch to pairing mode and will be searchable to pair with another device.

2. If the previously paired device is not nearby, follow the "Bluetooth Pairing" section.

Switching Between Paired Devices:

- Go to Bluetooth settings and disconnect the current connection with the headphones, then go into Bluetooth settings on the device you want to use and select "Connect".

Forgetting Bluetooth Pairing:

- When the headphones are on and not connected to any device, and after removing them from the charging case, pressing both headphones for 10 seconds will reset them.

5. Safety Information:

Before using the headphones, read the following tips to make the most of their capabilities and avoid dangerous or illegal situations.

Hearing Loss: